
C3-SSD INSTALL GUIDE

DIMENSIONAL RENDERINGS



Install Notes:

C3SSD

15″

- \checkmark 2 anchor points are located on each side of the doors interior frame (top, bottom, left and right)
- ✓ Due to wide variance of possible building materials, anchors are not included
- ✓ When inserting your anchors be sure to use a framing square to ensure the door is not pulled out of square
- ~ Additional framing and/or support underneath the rear (hanging portion) of the cabinet is recommended
- These specs are accurate but we always suggest having the product physically on site to ensure full understanding of how this ✓ product will coordinate with your build

C3SSD

13 1/2"

31″

19″

